



PRIME 12V BRUSHLESS

TRANSOM MOUNT ELECTRIC MOTOR

AFTER-SALES SERVICE AND SPARE PARTS

Scan this QR code to visit watersnake.com.au/pages/contact

Contact the Watersnake service centre for your country/region.

For spare parts, use these schematics and parts lists to find the part numbers you want. Then check with your nearest Watersnake service centre for pricing and availability.



INSTRUCTIONS FOR INSTALLING PARTS

Videos showing how to install many of our spare parts can be found here:


watersnake.com.au/pages/watersnake-motors-repair-instructions-for-users



SCHEMATICS AND PARTS LIST

WATERSNAKE PRIME 40LB-55LB MODELS

PARTS SCHEMATIC: LOWER UNIT




40LB-55LB MODELS

PARTS LIST: LOWER UNIT

KEY NUMBER	PART NUMBER	DESCRIPTION	QTY
1	HP8.034.132.8001	LOWER UNIT CASING	1
2	HP6.652.123.000	STATOR WINDING	1
3	HP8.662.124.000	O-RING	1
4	HP6.672.219.000	CONTROLLER 40LB/26"	1
	HP6.672.206.000	CONTROLLER 40LB/36"	1
	HP6.672.212.000	CONTROLLER 55LB	1
5	HP8.211.100.000	SHEATH	1
6	HP8.251.000.000	BUSHING	1
7	HP8.010.104.231	REAR COVER	1
8	HP8.247.178.000	INNER CARD SPRING	1
9	HP6.475.003.000	OIL SEAL	1
10	HP8.902.201.045	SCREW	3
11	HP8.210.870.000	SCREW SHEATH	3
12	HP8.902.204.000	SCREW	3
13	HP8.902.193.000	SCREW	2
14	HP7.690.004.000	ANODE PROTECTION BLOCK	1
15	HP8.662.137.000	O-RING	1
16	HP8.902.285.00	SCREW	2
17	HP8.220.455.027	SEALING RING	1
18	HP8.941.311.000	WASHER	1
19	HP8.940.383.000	WASHER	1
20	HP8.945.121.016	WAVE WASHER	1
21	HP8.245.031.016	E-CLIP	1
22	HP8.210.866.000	MAGNET STEEL SHEATH	1
23	HP8.530.076.007	MAGNET STEEL	3
24	HP8.530.075.007	MAGNET STEEL	3
25	HP6.300.216.000	ARMATURE SHAFT ASSEMBLY 40LB	1
	HP6.300.163.000	ARMATURE SHAFT ASSEMBLY 55LB	1
26	HP8.212.120.016	POSITIONING SLEEVE	1
27	HP6.622.030.000	ROTOR PUNCHING COMPONENT 40LB	1
	HP6.622.003.000	ROTOR PUNCHING COMPONENT 55LB	1
28	HP8.212.119.016	POSITIONING SLEEVE	1
29	HP8.251.001.000	OIL SEAL	1
30	HP6.260.000.000	BEARING	1

40LB-55LB MODELS

PARTS SCHEMATIC: HEAD, SHAFT, MOUNT, PROP.



40LB-55LB MODELS


PARTS LIST: HEAD, SHAFT, MOUNT, PROP.

KEY NUMBER	PART NUMBER	DESCRIPTION	QTY
31	HP6.482.009.000	PROPELLER NUT	1
32	HP8.325.021.8001	PROPELLER	1
33	HP8.264.157.000	SHEAR PIN	1
34	HP8.210.740.00	WIRE PROTECTIVE SLEEVE	1
35	HP6.657.191.999	SHAFT 26"	1
	HP6.657.174.999	SHAFT 36"	1
	HP6.657.173.999	SHAFT 42"	1
36	HP6.257.009.00	DEPTH COLLAR ASSEMBLY	1
37	HP8.902.143.45	SCREW	2
38	HP8.662.083.00	SEALING RING	1
39	HP8.610.201.45	CLAMP	1
40	HP8.903.059.00	SCREW	8
41	HP6.482.000.00	LOCKING NUT	1
42	HP8.220.378.70	BUSHING	1
43	HP8.926.045.45	BOLT	1
44	HP8.076.495.080	HEAD BOTTOM COVER	1
45	HP6.702.067.00	USB CONTROLLER	1
46	HP6.672.058.00	CONNECTOR	2
47	HP6.630.023.00	POTENTIOMETER ASSEMBLY	1
48	HP8.946.011.07	LOCKING WASHER	1
49	HP8.611.102.45	FIXED FRAME	1
50	HP8.634.116.00	WIRE GUARD	1
51	HP6.171.408.001	HEAD TOP COVER	1
52	HP8.667.032.00	FIXING CLAMP BOTTOM	1
53	HP8.667.018.00	FIXING CLAMP TOP	1
54	HP8.382.118.45	SPRING	1
55	HP8.303.030.00	CONNECTING SHAFT	1
56	HP6.465.117.00	HANDLE ASSEMBLY	1
57	HP8.903.078.00	SCREW	2
58	HP8.387.101.00	SPRING	1
59	HP6.428.023.00	WATER JOINT	1
60	HP8.662.109.00	SEAL COVER	1
61	HP8.034.105.00	ANDERSON PLUG	2
62	HP6.647.231.00	MAIN BATTERY CABLE	1
63	HP8.210.860.00	BUSHING	1
64	HP6.152.046.000	TRANSOM BRACKET ASSEMBLY	1
65	HP8.379.097.00	NUT	1
66	HP8.220.402.00	BUSHING	1
67	HP6.480.007.00	LOCK HANDLE	1

SCHEMATICS AND PARTS LIST

WATERSNAKE PRIME 70LB MODELS

PARTS SCHEMATIC: LOWER UNIT




70LB MODELS

PARTS LIST: LOWER UNIT

KEY NUMBER	PART NUMBER	DESCRIPTION	QTY
1	HP8.034.123.8003	LOWER UNIT CASING 70LB - 110LB	1
2	HP6.652.027.000	STATOR WINDING 70LB	1
3	HP8.662.124.000	O-RING	1
4	HP8.902.201.45	SCREW M3X8	3
5	HP8.210.870.000	SCREW SHEATH	3
6	HP6.672.213.000	CONTROLLER 70LB	1
7	HP8.210.867.000	WIRE SHEATH	1
8	HP8.010.098.231	REAR COVER	1
9	HP6.263.095.001	BEARING 15X32X9	1
10	HP8.941.299.016	CORRUGATED ELASTIC WASHER	2
11	HP8.247.170.016	INNER CIRCLIP	1
12	HP8.683.127.000	SKELETON OIL SEAL	1
13	HP8.683.124.000	SKELETON OIL SEAL	1
14	HP7.690.003.000	ANODE PROTECTION BLOCK	1
15	HP8.902.285.00	SCREW	3
16	HP8.902.193.000	SCREW	2
17	HP8.314.018.000	ARMATURE SHAFT	1
18	HP8.530.073.007	MAGNET STEEL 70LB	3
19	HP8.530.074.007	MAGNET STEEL 70LB	3
20	HP8.210.869.016	SHAFT SLEEVE	1
21	HP7.847.010.000	ARMATURE END PLATE	2
22	HP6.622.005.000	ROTOR LAMINATION ASSEMBLY 70LB	1
23	HP8.210.866.000	MAGNETIC STEEL JACKET	1
24	HP8.378.359.016	NUT	1
25	HP6.263.048.001	BEARING 12X28X8	1
26	HP8.247.171.016	CIRCLIP	1

70LB MODELS

PARTS SCHEMATIC: HEAD, SHAFT, MOUNT, PROP.



70LB MODELS

PARTS LIST: HEAD, SHAFT, MOUNT, PROP.

KEY NUMBER	PART NUMBER	DESCRIPTION	QTY
27	HP6.393.011.002	PROPELLER	1
28	HP8.264.569.00	SPLIT PIN	1
29	HP6.482.006.00	PROP NUT	1
30	HP8.940.625.00	WASHER	1
31	HP8.210.740.00	WIRE PROTECTIVE SLEEVE	1
32	HP6.657.174.999	SHAFT 36"	1
	HP6.657.173.999	SHAFT 42"	1
33	HP6.257.009.00	DEPTH COLLAR ASSEMBLY	1
34	HP8.902.143.45	SCREW	2
35	HP8.662.083.00	SEALING RING	1
36	HP8.610.201.45	CLAMP	1
37	HP8.903.059.00	SCREW	8
38	HP6.482.000.00	LOCKING NUT	1
39	HP8.220.378.70	BUSHING	1
40	HP8.926.045.45	BOLT	1
41	HP8.076.495.080	HEAD BOTTOM COVER	1
42	HP6.702.067.00	USB CONTROLLER	1
43	HP6.672.058.00	CONNECTOR	2
44	HP6.630.023.00	POTENTIOMETER ASSEMBLY	1
45	HP8.946.011.07	LOCKING WASHER	1
46	HP8.611.102.45	FIXED FRAME	1
47	HP8.634.116.00	WIRE GUARD	1
48	HP6.171.408.001	HEAD TOP COVER	1
49	HP8.667.032.00	FIXING CLAMP BOTTOM	1
50	HP8.667.018.00	FIXING CLAMP TOP	1
51	HP8.382.118.45	SPRING	1
52	HP8.303.030.00	CONNECTING SHAFT	1
53	HP6.465.117.00	HANDLE ASSEMBLY	1
54	HP8.903.078.00	SCREW	2
55	HP8.387.101.00	SPRING	1
56	HP6.428.023.00	WATER JOINT	1
57	HP8.662.109.00	SEAL COVER	1
58	HP8.034.105.00	ANDERSON PLUG	2
59	HP6.647.136.00	MAIN BATTERY CABLE 70LB	1
60	HP8.210.860.00	BUSHING	1
61	HP6.152.046.000	TRANSOM BRACKET ASSEMBLY	1
62	HP8.379.097.00	NUT	1
63	HP8.220.402.00	BUSHING	1
64	HP8.480.007.00	LOCK HANDLE	1

Scan to view the latest Watersnake
Prime 12V Brushless motor manuals:



www.watersnake.com.au/pages/watersnake-prime-brushless-transom-motor-manuals



WATERSNAKE[®]

AUSTRALIA, NEW ZEALAND, SOUTH AFRICA:

www.watersnake.com.au

EUROPE:

www.watersnake.eu.com

NORTH AMERICA:

www.watersnakeusa.com

Watersnake Distribution Pty. Ltd.
297-305 South Gippsland Highway
Dandenong South, Victoria 3175 Australia
ACN: 143 230 175

Watersnake[®] and Jarvis Marine[®] are registered
trademarks of Watersnake Distribution Pty. Ltd.

© Watersnake Distribution Pty. Ltd. All Rights Reserved.
Specifications are subject to change
without notice.